



YAK-BONE

TOOLS NEEDED

- 1/2" Wrench
- 15/16" Wrench

INSTALLATION INSTRUCTIONS

1. Insert the TOP SUPPORT into the HITCH POST.



2. Slide the TOP SUPPORT to the desired height setting and insert the WIRE LOCK PIN to secure.



3. Set the end of the TOP SUPPORT extrusion into the mold of the EAR and fasten, using the .3125" FLAT WASHERS and .3125" HEX BOLTS.



INSTALLING TO HITCH

4. Insert the YAK-BONE into a 2" trailer hitch and secure with the a 0.625" HEX BOLT and LOCK WASHER and tighten.



PARTS LIST

- A - 1 x TOP SUPPORT
- B - 1 x HITCH POST
- C - 1 x WIRE LOCK PIN
- D - 1 x .625 HEX BOLT
- E - 1 x .625 LOCK WASHER
- F - 2 x EAR
- G - 2 x .3125 HEX BOLT
- H - 2 x .3125 FLAT WASHER

