



ODC RUDDER

TOOLS NEEDED

- Short Phillips Screwdriver
- Super Glue

INSTALLATION INSTRUCTIONS

1. Remove factory rudder. Be sure to keep track of the hardware.
2. Glue a SPACER to each side of the ODC rudder, making sure the holes are perfectly aligned.
3. Reattach the metal clip and bolt the ODC RUDDER into place with a Phillips Head Screwdriver.
4. Tie the rudder lift cord to the hole in the ODC RUDDER.



PARTS LIST

A - 1 x RUDDER BLADE

B - 2 x SPACER

C - HARDWARE (use factory hardware)